

IMPORTANT: IN THE INTEREST OF PRODUCT PERFORMANCE AND SAFETY PLEASE READ THESE INSTALLATION AND WARRANTY INSTRUCTIONS BEFORE INSTALLING THE PRODUCT.



SAL products are designed in accordance with all mandatory International and Australian Standards, which require installation in accordance with As/NZ33000 by a qualified installer and regular cleaning and maintenance of the equipment. Products are sold in accordance with the following instructions and SAL standard terms and conditions of sale, available via www.sal.net.au.

Due to continued product and information updates, product data sourced from sal.net.au shall not form part of any contract and or technical performance guarantee unless expressly confirmed in writing by SAL at the time of order.

QUICK CONNECT ESS107 SURFACE SOCKET electrical and installation specification effective 18/6/2022.

Model No. | Input (V)/(Hz) | Min / May loads | Calculate | Dimension | x W x H

\* IP rating ALL products: Termination of the product must be made in accordance with the IP rating.

ESS107	250VAC	10A	WH			T T
			**	IIIE	70 x 56 x 45 mm	N/A
Nominal frequency (Hz)		50		Product installation orientation		Ceiling cavity
Operating ambient min/max (°C)		0 to 40		Product application		Interior residential or commercial
Operating humidity		10% to 85% RH, NC		Pixie connectivity		N/A
Storage ambient limit (°C)		0 to 60		* IP rating		20
Storage humidity		10% to 85% RH, NC Att		Attachr	ment type	N/A
* IP rating for interior	products: The d	lesignated IP rating is "	from be	low the	ceiling" unless otherwise	specified.

## General product application requirements (if applicable):

- 1. CCT or POWER selections (where supplied) IMPORTANT, where CCT colour temperature or POWER selection switching is provided, it is important to switch OFF the power before the selection is made, otherwise equipment damage may occur.
- 2. Recycling SAL encourages recycling, please consider the environment when disposing of packaging, batteries & components.
- Switching or test intervals For optimum product performance, good design practice does not encourage 24/7 operation of lighting products without
  the provision of a routine switching or regulatory test cycle. As a guide for continual operation installations, a twelve [12] hour duration for industrial and
  Commercial applications and as key follow duration for Residential applications should be considered.
- 4. Product maintenance In line with the relevant design standards and to protect your investment, it is important to have in place a routine cleaning program that

reflects the installation environment and maintains the product in a clean and functional condition.

IMPORTANT - The supply must be isolated before any product maintenance or cleaning is conducted. In addition, damage to ANY cable or card supplied with the product must be addressed as follows; For attachment type X hoving a specially prepared cable, if the external flexible cable is damaged, if must be replaced by an equivalent cable exclusively variable from the manufacturer or authorised installer. For attachment type Y, if the external flexible cable is damaged, it must be exclusively replaced by an equivalent cable by the manufacturer or authorised installer. For attachment type Z, if the external flexible cable is damaged, the cable cannot be replaced and the luminair must be destroyed.


- 5. Adverse, corrosive and coastal installation environments Unless the product is specifically designated for such applications in these installation instructions, which is supported by a professional maintenance program; installation of equipment in such environments is not recommended.
- 6. Dimming products Dimming circuits and product compatibility must be validated by the installer before installation; SAL cannot be responsible for third party changes in dimmer compatibility.
- Suspended products For installation safety, any suspended products must NOT be installed in high air movement spaces or locations subject to impact.
- 8. Light source replacements (Non-replaceable light sources) The light source of the product is deemed not replaceable, when the product reaches its end of life the compilete product, if must be replaced by a qualified installer, (Non-user replaceable light sources) – The light source of the product must only be replaced by the manufacturer or qualified installer. Caudin, risk of electric shock.
- Interior downlights and sensors with remote drivers The mounting facilities provided for the transformer/driver (if any), need only be utilized if in the application of the product is required by AS3000. Drivers are not designed for installation environments that restrict conventional airflow.
- 10. Roodlight products Unless nominated aiming restrictions or installation parameters apply, products are designed for installation environments between ground and 15 metres in height, subject to the desired optical performance being achieved.
- Emergency enabled products In the interest of transport and safety, emergency products are supplied with the battery disconnected. In addition to specific
  emergency commissioning instructions, this battery MUST be connected at the time of installation.






12. Specific installation procedures (if any) - this device must be installed by a licensed electrician:





Strip the outer sheath only from the cable, leaving single insulation to a length of 46mm. An outer sheath stripping length guide is found on the lid of the quick connector.



Separate individual cables and place each in the quick connector base channel according to the colour guide. Closed the lid, ensuring the conductors remain in their correct channel, and then pull lever to the closed position.

Note: Connecting pins will pierce through the insulation and securing clips will hold the connections in place. Once depth we progred the quick connector, place a standard screwditive rish the securing clip found on the moulding and twist. Respect on the other will be securing clip found on the moulding and twist. Respect on the other side of the quick connector. The mounting facilities provided, need only be utilized if in the application of the product is required by ASS000.

13. Warranty—in accordance with SAL's standard terms and conditions of sale, SAL warrant this product to be the for firm defects in materials and or workmantly for a period as stated below for goods not subject to incorrect installation, maintenance, operation, mishanding, environmental, unauthorised modifications or electrical operating conditions outside the nominated product specification as detailed in these installation instructions. The benefits to you given by this warranty are in addition to other rights and remedies you have under law. Our goods come with guarantees that cannot be excluded under the Austration Consumer Law. You are entitled to a replacement or refund for a major failure and consensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Warranty term - Residential usage (12) months, Commercial usage (12) months from date of purchase.

## How to make a claim?

Slep # 1 – Within 30 days of the fault discovery, please contact the original place of the SAL product purchase during standard (local) business hours, with the following information (a) proof of purchase (b) description and quantity of the claimed fault (c) address of installation. (d) operating hours of the product.

Step #2 - It is then the responsibility of the original place of product purchase to report the matter to SAL aftersales;

Step #3 - Upon review of your claim and if the product is required to be returned to SAL for technical evaluation, then at the owners expense the product must be returned to SAL as per the above nominated locations.

Slep 44 - Pending the evaluation, the claim will be validated resulting in the product being repoted or replaced with the same or best equivalent product of the discretion of SAL, or rejected if the product foult was found to be caused by conditions beyond the responsibility of SAL warranty obligations. Consideration of installation, product removal, return feight and or testing fees are not the responsibility of SAL.

