

IMPORTANT: IN THE INTEREST OF PRODUCT PERFORMANCE AND SAFETY PLEASE READ THESE INSTALLATION AND WARRANTY INSTRUCTIONS BEFORE INSTALLING THE PRODUCT.



SAL products are designed in accordance with all mandatory International and Australian Standards, which require installation by a qualified installer and regular cleaning and maintenance of the equipment. Products are sold in accordance with the following instructions and SAL standard terms and conditions of sale, which are available via www.sal.net.au.

PIXIE SGW/BT GATEWAY product electrical and installation specification effective 4/07/2019.

	Model No.	Input	Min / Max loads	Colour	Dimension L x W x H (mm)	Dimming Technique	Wireless
ſ	SGW/BT	5V DC - 1A	N/A	Matt Black	95 x 95 x 24	N/A	Bluetooth Mesh Technology

Nominal frequency (Hz)	50	Product installation orientation	Horizontal wall mount or desktop		
Operating ambient min/max (°C)	0 to 40	Product application	Interior residential or commercial		
Operating humidity	10% to 85% RH, NC	Pixie connectivity	Yes		
Storage ambient limit (°C)	0 to 40	*IP rating	20		
Storage humidity	10% to 85% RH, NC	Attachment type	N/A		
*IP rating for interior products: The designated IP rating is "from below the ceiling" unless otherwise specified.					
*IP rating ALL products: Termination of the product must be made in accordance with the IP rating.					

General product application requirements (where applicable):

- 1. **CCT or POWER selection (where supplied)** IMPORTANT, where CCT or POWER selection switching is provided, it is important to switch OFF the SUPPLY before the CCT selection is made, otherwise equipment damage may occur.
- 2. Recycling SAL encourages recycling, please consider the environment when disposing of packaging, batteries & components.
- 3. **Switching or test intervals** For optimum product performance, good design practice does not encourage 24/7 operation of lighting products without the provision of a routine switching or regulatory test cycle. As a guide for continual operation installations, a twelve (12) hour duration for Industrial and Commercial applications and six (6) hour duration for Residential applications should be considered.
- 4. **Product maintenance** In line with the relevant design standards and to protect your investment, it is important to have in place a routine cleaning program that reflects the installation environment and maintains the product in a clean and functional condition.

IMPORTANT - The supply must be isolated before any product maintenance or cleaning is conducted. In addition, damage to ANY cable or cord supplied with the product must be addressed as follows; For attachment type X having a specially prepared cable, if the external flexible cable is damaged, it must be replaced by an equivalent cable exclusively available from the manufacturer or authorised installer. For attachment type Y, if the external flexible cable is damaged, it must be exclusively replaced by an equivalent cable by the manufacturer or authorised installer. For attachment type Z, if the external flexible cable is damaged, the cable cannot be replaced and the luminaire must be destroyed.

- 5. Adverse, corrosive and coastal installation applications Unless the product is specifically designated for such applications in these installation instructions, which is supported by a professional maintenance program; installation of equipment in such environments is not recommended.
- 6. **Dimming products** Dimming circuits and product compatibility must be validated by the installer before installation; SAL cannot be responsible for third party changes in dimmer compatibility.
- 7. Suspended products For installation safety, any suspended products must NOT be installed in high air movement spaces or locations subject to impact.
- 8. **Light source replacements** (non-replaceable light sources) The light source of the product is deemed not replaceable, when the product reaches its end of life, the complete product must be replaced by a qualified installer. (Non-user replaceable light sources) The light source of the product must only be replaced by the manufacturer or qualified installer. **Caution, risk of electric shock.**
- 9. Interior downlights and sensors with remote drivers The mounting facilities provided for the transformer/driver (if any), need only be utilized if in the application of the product is required by AS3000. Drivers are not designed for installation environments that restrict conventional airflow.
- 10. **Floodlight products** Unless nominated aiming restrictions or installation parameters apply, products are designed for installation environments between ground and 15 metres in height, subject to the desired optical performance being achieved.



11. Specific installation procedures & feature: (if any)

- Black matt finish, low profile design
- Three LED indicators to display system status
- 240V power supply included
- Plug and play with PIXIE PLUS App
- Wi-Fi and internet connectivity, control your PIXIE devices from anywhere in the world
- Compatible with Google Home and Amazon Alexa
- Designed for USE WITH SAL PIXIE SMART PRODUCTS ONLY

Operation instruction

- To start working, connect PIXIE Gateway with power supply, plug power supply to the mains
- Follow the guides in PIXIE PLUS App to finish all the configurations

Operation of SET button

Long press for 5 seconds	Reboot PIXIE Gateway, reconnect all the network		
Quickly press 9 times	Manually reset the PIXIE Gateway		

LED Indicator status

Indicator Status	0	<u> </u>	*
Red blinking	Ready for configuration	Ready for configuration	Ready for configuration
Red	Device is not online, please check your internet connection	Device is not online, please check your router setting	
Blue blinking	Connecting	Connecting	Connecting
Blue	Device is online	Local router connection is successful	PIXIE Bluetooth network is set

Need more help?

- Tap "Help" under "Setting" in PIXIE PLUS App
- Tap "Email us" under "Setting" in PIXIE PLUS App
- Visit SAL website https://www.sal.net.au/contact-us

Installation instruction

1. Installation

- Choose a position within range of your Wi-Fi router and a PIXIE device
- For optimal connectivity, place PIXIE Gateway at an open area, which is not inside a drawer or cabinet
- Connect PIXIE Gateway with power supply, plug power supply to the mains
- Three LED indicators will turn on and blink in red, showing it's ready to configure
- Download the latest PIXIE PLUS App, and you are ready to go!

2. Setup PIXIE Gateway (For new users)

- Hold your phone and stand close to the PIXIE Gateway
- Launch PIXIE PLUS App, register an account and login
- Choose "Create a HOME"
- Search until the PIXIE Gateway is found by the App
- Important: select the correct gateway (check the gateway ID on the label under gateway body)
- Follow the guides to choose your Wi-Fi network
- When three LED indicators turn static blue, it's all set

3. Setup PIXIE Gateway (For existing PIXIE app users who wish to transfer existing data & settings to the PIXIE PLUS app)

- Make sure the PIXIE app and PIXIE PLUS app are up-to-date
- Hold you phone and stand close to the PIXIE Gateway
- Launch PIXIE PLUS App, register an account and login
- Select the option "Transfer HOME" at welcome page
- Follow the guides and confirm the data transfer
- Search until the PIXIE Gateway is found
- Important: Select the correct gateway (check the gateway ID on the label under gateway body)
- Follow the guides to set up Wi-Fi connection
- When three indicators turn static blue, it's all set

4. Link with Google Home

- Launch Google Home App
- Make sure login with a Google account
- Tap "Add" and then "Set up device"
- Tap "Works with Google"
- Search for and add "SAL PIXIE Plus", then login and authorise

12. Warranty – In accordance with SAL standard terms and conditions of sale, SAL warrant this product to be free from defects in materials and or workmanship for a period as stated below for goods not subject to incorrect installation, maintenance, operation, mishandling, environmental, unauthorised modifications or electrical operating conditions outside the nominated product specification as detailed in these installation instructions. The benefits to you given by this warranty are in addition to other rights and remedies you have under law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Warranty term - Twelve (12) months for commercial use and twenty four (24) months for residential use from date of purchase.

How to make a claim?

Step # 1 – Within 30 days of the fault discovery, please contact the original place of the SAL product purchase during standard (local) business hours, with the following information (a) proof of purchase (b) description and quantity of the claimed fault (c) address of installation. (d) operating hours of the product.

Step # 2 - It is then the responsibility of the original place of product purchase to report the matter to SAL aftersales;

 NSW | ACT | QLD
 - SAL National Pty Ltd, 40 Biloela Street Villawood NSW 2163
 | P # 02 9723 3099

 QLD
 - SAL National Pty Ltd, 36 Whitelaw Place Richlands QLD 4077
 | P # 07 3879 5999

 VICT | TAS | SA | NT
 - SAL National Pty Ltd, 46-48 Keys Road Moorabbin Victoria 3189
 | P # 03 9532 3168

 WA
 - SAL National Pty Ltd, 29 Beringarra Av Malaga WA 6090
 | P # 08 9248 7458

Step # 3 – Upon review of your claim and if the product is required to be returned to SAL for technical evaluation, then at the owners expense the product must be returned to SAL as per the above nominated locations.

Step # 4 – Pending the evaluation, the claim will be validated resulting in the product being repaired or replaced with the same or best equivalent product at the discretion of SAL, or rejected if the product fault was found to be caused by conditions beyond the responsibility of SAL warranty obligations. Consideration of installation, product removal, return freight and or testing fees are not the responsibility of SAL.